

ASSEMBLY INSTRUCTIONS

PT-72P & PT-72M TABLES ASSEMBLY INSTRUCTIONS



*Model views may not represent exact model purchased

TABLE OF CONTENTS

ASSEMBLY COMPONENTS	3
APRON TO LEG ATTACHMENT	4
LEG ASSEMBLY	5

ASSEMBLY COMPONENTS

ITEMS INCLUDED	PART#		PART#
1-LEG KIT,TABLE		1-APRON ASSY,TABLE	
1-TOP,TABLE		BOX,TABLES	
SCREW,#12.00X1 1/2	100062		

REV DESCRIPTION DATE

 Original Created	6-18-09	NAM


Assembly Instructions for Tables

Items not included but needed for assembly:


1. ½" wrench

Instructions:

1. Lay the table on the floor with the apron side up. (Be sure to lay the table on a clean surface so you don't damage the tabletop.)




2. Take each of the table legs and insert the stud bolt through the hole in the steel corner brace.



3. Apply a lock washer and a 5/16" nut onto each stud bolt. Tighten each nut using a minimum of 12 foot-pounds but not exceeding 17 foot-pounds of torque.



- 4. Slide leg boots onto the legs with the flared end toward the bottom of the leg.
- 5. Screw leg levelers into t-nut in the bottom of the leg.



- 6. Turn the table over so the top is up. Set your table in place and adjust the leg levelers to level the table.
- 7. Slide the leg boot down to the floor.